



Teile und Zubehör - Einbauanleitung

Nachrüstung Sonnenblenden seitlich BMW 3er Limousine (E 46/4)

To retrofit side sun visors
BMW 3 Series Saloon (E 46/4)

Pare-soleil latéraux de deuxième monte
BMW Série 3 berline (E 46/4)

Naderhand in te bouwen zonnekleppen
aan de zijkant
BMW 3-serie sedan (E 46/4)

Montage der Halter

To install the holders
Montage des supports
Montage van de houders
Montera hållaren
Montaggio dei supporti
Montaje de los soportes
Montagem do suporte

Montage der Sonnenblenden

To install the sun visors
Montage des pare-soleil
Montage van de zonnekleppen
Montera solskydden
Montaggio degli schermi parasole
Montaje de los parasoles
Montagem das palas para o Sol

Demontage der Halter

To remove the holders
Démontage des supports
Verwijderen van de houders
Demontera hållaren
Smontaggio dei supporti
Desmontaje de los soportes
Remoção do suporte

Eftermontering av solskydd på sidorna
BMW 3-serie sedan (E 46/4)

Postmontaggio schermi parasole laterali
BMW Serie 3 berlina (E 46/4)

Reequipamiento de parasoles laterales
BMW Serie 3 berlina (E 46/4)

Montagem lateral de palas para o Sol
nos modelos BMW da Série 3, Berlina (E 46/4)

